

WOOD PELLET CENTRAL HEATING SYSTEMS - NORDIC BIO ENERGY -



OPOP & DOR WOOD PELLET BOILERS SCOTTE CONTROL PANEL - WIRING SUPPLEMENT -

Power to the Control Panel

The control box requires a permanent supply to the 230volt connectors on the printed circuit board and should be used in conjunction with a "high limit stat."

The connection point is shown as "mains lead" on the wiring diagram (right hand side of the lower board).

Timing the Boiler

If the boiler is to be controlled by a time clock, this must be a VOLT FREE CONTACT time clock only.

The volt free contact time clock is to be connected to the control panel by replacing the "external switch link" from the connectors on the board with the cable from the timer.

The connection point is shown as "0 volt" on the wiring diagram (left hand side of the lower board).

Power to the Circulating Pump

The circulating pump requires a permanent 230volt supply and should be used in conjunction with a "pump stat.".

The wiring diagram can be found on the reverse of this page.

Wednesday
5pm to 8pm

Thursday & Friday
10am to 5pm

Saturday
10am to 2pm



Unit 6 Ridgeview
Monavalley Business Park
Tralee
County Kerry

t : 066 711 8884

f : 066 711 8042

w : kerrybiofuels.ie

